



DUAL THREAD STUD

ST204

Application Manual



THE STINGER ST204 DUAL THREAD STUD



1. STEP ONE

Insert Stinger stud into the 4.2mm pre drilled hole.



2. STEP TWO

Drill the Stinger stud with the purpose made socket into the hole.



3. STEP 3

Fasten the Stinger strain isolator or Stinger tensioner or Stinger intermediate isolator onto the Stinger stud as shown below;

